

SPARE PARTS CATALOGUE

P7500i INVERTER, Single phase, 230V, 50Hz, Electric start / Petrol


Power Generator | Generating sets

Valid for machine code: PF752SXB000

Revision: 0




PF752SXB000 - FRAME / TELAIO



PF752SXB000 - FRAME / TELAIO


Position	Part Number	Description	Note
1	PGL00185	Seal ring	
2	PGL00178	Hexagon bolt with flange	
3	PGL00186	Lever connecting bracket	
4	PGL00187	Seal ring	
5	PGL00144	Hexagon bolt with flange	
6	PGL00191	Components of frame	
7	PGL00188	Lever connecting bracket	
8	PGL00189	Seal ring	
9	PGL00190	Cushioning rubber	
10	PGL00266	Earth wire of general-purpose engine	
11	PGL00184	Exterior Cover(right)	
12	PGL00194	Cushioning rubber	
13	PGL00193	Seal ring	
14	PGL00192	Frame girder	
15	PGL00349	Socket head screw	
16	PGL00206	Exterior Cover(left)	
17	PGL00244	Lever combination	
18	PGL00141	Cap nut	

PF752SXB000 - TANK / SERBATOIO



Position	Part Number	Description	Note
80	PGL00202	Tank oilout	
108	PGL00230	Tank Cover	
109	PGL00231	Pouring orifice filter screen combination	
110	PGL00232	Seal ring	
111	PGL00233	Cross recessed countersunk head screw	
112	PGL00234	Oil level sensor	
114	PGL00236	Liner tube of tank damping cushion	
115	PGL00237	Tank damping cushion	
116	PGL00238	Tank	


PF752SXB000 - MUFFLER GUARD SHIELD /Protezione del silenziatore



PF752SXB000 - MUFFLER GUARD SHIELD /Protezione del silenziatore

Position	Part Number	Description	Note
1	PGL00215	Muffler reinforcement plate	
2	PGL00216	Hexagon bolt with flange	
3	PGL00199	Cushioning rubber	
4	PGL00197	Muffler guard shield	
5	PGL00198	Hexagon bolt with flange	
6	PGL00174	Hexagon bolt with flange	
7	PGL00217	Heat insulation cotton （Glass fiber）	
8	PGL00218	Muffler heat insulating plate	
9	PGL00239	Muffler guard shield	
10	PGL00157	Hexagon nut with flange	
11	PGL00240	Seal ring	
12	PGL00241	Seal ring	
13	PGL00242	Frame guard shield	
14	PGL00243	Hexagon bolt with flange	


PF752SXB000 – MUFFLER ASSY / SILENZIATORE ASSEMBLATO



PF752SXB000 – MUFFLER ASSY / SILENZIATORE ASSEMBLATO

Position	Part Number	Description	Note
1	PGL00220	Muffler	
2	PGL00264	Spark collector	
3	PGL00265	Flame screen	
4	PGL00200	Arrester spark maintenance cover	
5	PGL00196	Hexagon bolt with flange	
6	PGL00211	Hexagon nut with flange	
7	PGL00219	Bushing	
8	PGL00221	Muffler gasket	
9	PGL00222	Outlet pipe	
10	PGL00223	Outlet gasket	
11	PGL00224	Allmetal hexagon locknut	
12	PGL00225	Hexagon bolt with flange	

PF752SXB000 – CONTROL PANEL ASSY / Pannello di controllo assemblato




PF752SXB000 – CONTROL PANEL ASSY / Pannello di controllo assemblato

Position	Part Number	Description	Note
1	PGL00246	Control panel harness	
2	PGL00133	Components of control panel	
3	PGL00255	Start control switch	
4	PGL00256	Idle switch	
5	PGL00257	Earth terminal combination	
6	PGL00254	USB/AUX	
7	PGL00260	tarpaulin	
8	PGL00258	Outlet	
9	PGL00259	Outlet	
10	PGL00251	Overcurrent protector	
11	PGL00252	Overcurrent protector	
12	PGL00253	Power socket combination	
13	PGL00074	Power socket combination	
14	PGL00261	Power plug combination	
15	PGL00262	Connecting wire	
15	PGL00139	cable connection panel	
16	PGL00130	Cross recessed small pan head screw	
17	PGL00131	Oil switch knob	
18	PGL00132	Cross small pan head screws / pad COMP.	
19	PGL00134	Multifunctional indicating meter	
20	PGL00136	Hexagon nut with flange	

PF752SXB000 – CONTROL PANEL ASSY / Pannello di controllo assemblato


Position	Part Number	Description	Note
21	PGL00135	Start control switch	
22	PGL00138	Panel bed	
23	PGL00137	Hex head flange bolt axial	
24	PGL00140	Clip nut	
25	PGL00141	Cap nut	
26	PGL00129	battery maintainance cover	
27	PGL00128	Slotted pan head screw with waisted shank	

PF752SXB000 – STORAGE BATTERY / Batterie di accumolo



Position	Part Number	Description	Note
1	PGL00161	Battery Cushion	
2	PGL00160	Hexagon bolt with flange	
3	PGL00132	Cross small pan head screws / pad COMP.	
4	PGL00159	Battery baffle	
5	PGL00267	Storage battery	
6	PGL00171	Strap	


PF752SXB000 – LEVER COMBINATION / Combinazione leve



PF752SXB000 – LEVER COMBINATION / Combinazione leve

Position	Part Number	Description	Note
1	PGL00125	Hex head flange bolt axial	
2	PGL00126	Flat washer	
3	PGL00127	Washer	
4	PGL00163	Socket head screw	
5	PGL00162	Socket head screw	
6	PGL00164	Handlebar Connecting seat	
7	PGL00165	Lever Rubber	
8	PGL00166	Lever location block	
9	PGL00167	Locking handle	
10	PGL00168	Tension spring	
11	PGL00169	Handlebar Connecting seat	
12	PGL00170	Lever Rubber	
13	PGL00245	Lever combination	


PF752SXB000 – SUPPORTING WHEEL / Supporti Ruote



PF752SXB000 – SUPPORTING WHEEL / Supporti Ruote


Position	Part Number	Description	Note
1	PGL00208	Hexagon nut with flange	
2	PGL00209	Engine Support plate	
3	PGL00210	Engine Support plate	
4	PGL00212	Machine buffering seat	
5	PGL00213	Machine buffering seat	
6	PGL00214	Machine buffering seat	
7	PGL00211	Hexagon nut with flange	
8	PGL00205	FRAME COMP Backplane	
9	PGL00132	Cross small pan head screws / pad COMP.	
10	PGL00201	Oil releasing rubbe	
11	PGL00180	Pin clip	
12	PGL00181	Flat washer	
13	PGL00182	Components of supporting wheel	
14	PGL00183	Machine set supporting wheel shaft	
15	PGL00178	Hexagon bolt with flange	
16	PGL00177	Bracket of frame shock absorbing seat	
17	PGL00179	Bracket of frame shock absorbing seat	
18	PGL00248	Hexagon bolt with flange	

PF752SXB000 – AIR GUIDE HOOD / Copertura guida aria




Position	Part Number	Description	Note
1	PGL00132	Cross small pan head screws / pad COMP.	
2	PGL00150	wind scooper	
3	PGL00247	Self control constant current charger	
4	PGL00172	wind scooper	
5	PGL00176	Location wire nail	
6	PGL00174	Hexagon bolt with flange	
7	PGL00173	Seal ring	
8	PGL00175	wind scooper	

PF752SXB000 – INVERTER




Position	Part Number	Description	Note
1	PGL00151	Hexagon bolt with flange	
2	PGL00152	Flat washer	
3	PGL00153	Cushioning rubber	
4	PGL00154	Bushing	
5	PGL00144	Hexagon bolt with flange	
6	PGL00155	Inverter assy	
7	PGL00263	Earth wire of general-purpose engine	
8	PGL00142	Fuse box combination	

PF752SXB000 – COMBINATION SWITCH / Combinazione degli interuttori




Position	Part Number	Description	Note
1	PGL00143	Combination Switch	
2	PGL00132	Cross small pan head screws / pad COMP.	
3	PGL00046	Components of oil switch	
4	PGL00144	Hexagon bolt with flange	
5	PGL00145	Clip combination	
6	#N/A	Oil tube	
7	#N/A	Oil tube	
8	PGL00084	Fuel filter	
9	PGL00146	Oil tube	
10	PGL00147	Clip combination	

PF752SXB000 – TRIGGER PUMP / Pompa a Leva




Position	Part Number	Description	Note
1	PGL00284	Hexagon bolt with flange	
2	PGL00283	Trigger comp	
3	PGL00160	Hexagon bolt with flange	
4	PGL00282	Trigger bracket	
5	PGL00297	Strap	

PF752SXB000 – STARTING MOTOR / Motori di avviamento




Position	Part Number	Description	Note
1	PGL00270	Components of starting motor	
2	PGL00269	Hexagon bolt with flange	

600-699 / EXHAUST - Scarico




Position	Part Number	Description	Note
1	PGL00156	Hexagon bolt with flange	
2	PGL00290	Starting disc	
3	PGL00289	Impeller	
4	PGL00287	Hexagon nut with flange	
5	PGL00286	Motor rotor	
6	PGL00285	Hexagon bolt with flange	
7	PGL00280	Motor stator	
8	PGL00276	Lighter	
9	PGL00297	Strap	
10	PGL00156	Hexagon bolt with flange	

PF752SXB000 – STARTER ASSEMBLY – Assieme di avvio




Position	Part Number	Description	Note
1	PGL00288	Fan cover comp.	
2	PGL00156	Hexagon bolt with flange	
3	PGL00144	Hexagon bolt with flange	
4	PGL00291	Manual starting components	
5	PGL00195	Hexagon bolt with flange	
6	PGL00203	Cable cleat	
7	PGL00292	Location wire nail	
8	PGL00293	Location wire nail	

PF752SXB000 – CARBURETOR ASSY – Carburatore assemblato




Position	Part Number	Description	Note
1	PGL00335	Carburetor gasket	
2	PGL00336	Heat insulating pad for carburetor	
3	PGL00337	Carburetor gasket	
4	PGL00338	Carburetor	
5	PGL00339	Mounting bracket of speed-regulated step motor	
6	PGL00340	Cross recessed pan head screw	
7	PGL00341	Cross recessed pan head screw	
8	PGL00342	Stepping motor	
9	PGL00081	Stepping motor	

PF752SXB000 – AIR CLEANER ASSY – Filtro aria assemblato



Position	Part Number	Description	Note
1	PGL00313	Air filter	
2	PGL00279	Air filter element combination	
3	PGL00204	Air filter element	
4	PGL00156	Hexagon bolt with flange	
5	PGL00157	Hexagon nut with flange	
6	PGL00312	Stay stud	




PF752SXB000 – GAS DISTRIBUTION SYSTEM – Sistema di distribuzione del gas



PF752SXB000 – GAS DISTRIBUTION SYSTEM – Sistema di distribuzione del gas

Position	Part Number	Description	Note
1	PGL00156	Hexagon bolt with flange	
2	PGL00327	Valve rocker combination	
3	PGL00326	Valve rocker shaft	
4	PGL00325	Push rod	
5	PGL00347	Lifter, Valve	
6	PGL00332	Valve Kit	
7	PGL00343	Valve oil seal	
8	PGL00345	Seat, valve spring	
9	PGL00344	Inner spring of valve	
10	PGL00102	Retainer, valve spring	
11	PGL00101	Valve locker	
12	PGL00346	Valve adjustment cap	


PF752SXB000 – PISTON ROD ASSY – Asta del pistone assemblato



PF752SXB000 – PISTON ROD ASSY – Asta del pistone assemblato

Position	Part Number	Description	Note
1	PGL00314	Connecting rod	
2	PGL00316	Piston	
3	PGL00317	Piston pin	
4	PGL00315	Steel cable baffle ring	
5	PGL00318	Piston ring combination	
6	PGL00305	Camshaft assy	
7	PGL00299	crankshaft	
8	PGL00298	Balancing shaft	


PF752SXB000 – CRANKCASE COVER / Copertura del carter



PF752SXB000 – CRANKCASE COVER / Copertura del carter

Position	Part Number	Description	Note
1	PGL00304	ocation pin	
2	PGL00306	Crankcase cover gasket	
3	PGL00302	Bearing	
4	PGL00308	Crankcase cover	
5	PGL00307	Bearing	
6	PGL00311	Hexagon bolt with flange	
7	PGL00294	Oil seal	
8	PGL00310	Oil rule combination	
9	PGL00309	FLYWHEEL COMP	
10	PGL00285	Hexagon bolt with flange	
11	PGL00287	Hexagon nut with flange	


PF752SXB000 – CRANKCASE COVER / Copertura del carter



PF752SXB000 – CRANKCASE COVER / Copertura del carter

Position	Part Number	Description	Note
1	PGL00278	Side plate	
2	PGL00156	Hexagon bolt with flange	
3	PGL00268	air deflector	
4	PGL00277	Crankcase body	
5	PGL00300	Flat washer	
6	PGL00301	Sealing plug screw	
7	PGL00294	Oil seal	
8	PGL00296	ocation pin	
9	PGL00302	Bearing	
10	PGL00303	Oil level sensor	
11	PGL00174	Hexagon bolt with flange	
12	PGL00297	Strap	
13	PGL00281	Pressing plate	
14	PGL00174	Hexagon bolt with flange	

PF752SXB000 – CYLINDER HEAD / Testata dei cilindri



PF752SXB000 – CYLINDER HEAD / Testata dei cilindri

Position	Part Number	Description	Note
1	PGL00156	Hexagon bolt with flange	
2	PGL00334	air deflector	
3	PGL00295	Cylinder Temperature Sensor	
4	PGL00333	Breather tube	
5	PGL00331	Cylinder head cover	
6	PGL00330	PACKING, BREATHER CHAMBER	
7	PGL00329	CAP,BREATHER CHAMBER	
8	PGL00144	Hexagon bolt with flange	
9	PGL00328	Gasket for cylinder head cover	
10	PGL00327	Valve rocker combination	
11	PGL00326	Valve rocker shaft	
12	PGL00325	Push rod	
13	PGL00324	Hexagon bolt with flange	
14	PGL00030	Spark plug	
15	PGL00322	Stud	
16	PGL00321	Cylinder head	
17	PGL00323	Stud	
18	PGL00320	Gasket for cylinder head	
19	PGL00319	ocation pin	

PRAMAC

SERVICE & PARTS