

SPARE PARTS CATALOGUE


GENERATING SET PMI6500

Consumer Generator | Generating sets

Valid for machine code: PR552SXB000

Revision: 0

BASEFRAME



BASEFRAME

Position	Part Number	Description	Note
2	PGZ00132	Control Panel	
4	#N/A	Front Cover	
5	#N/A	Wire Jacket	
7	PGZ00133	Wire Harness	
8	PGZ00134	Inverter	
9	#N/A	Engine	
10	#N/A	Column	
11	PGZ000135	DC Voltage Regulator	
12	#N/A	Push Lug	
13	#N/A	Across Bar	
15	#N/A	Damping Pad	
16	#N/A	Left Hull	
17	PGZ00136	Left Cover Board	
19	PGZ00137	Fuel Cap	
20	#N/A	Fuel Tank Outlet Seal Ring	
23	#N/A	Upper Housing Assem	
24	#N/A	Upper Handle Assembly	
28	#N/A	Fuel Hose	
29	#N/A	Fuel Hose	
30	#N/A	Clip	
31	#N/A	Fuel Tee Pipe	
32	#N/A	Damping Pad	
33	PGZ00138	Fuel Tank	
34	#N/A	Fuel Tank Nipple	


BASEFRAME

Position	Part Number	Description	Note
36	#N/A	Fuel Hose	
38	#N/A	Fuel Tee Pipe	
39	#N/A	Fuel Hose	
40	#N/A	Bearing Clamp Ring	
41	#N/A	Column	
42	#N/A	Column	
43	PGZ00118	Gasket, Muffler	
44	#N/A	Rear Cover	
45	#N/A	Service Window	
46	#N/A	Column	
47	#N/A	Push Lug	
48	#N/A	Switch Assembly	
49	#N/A	Right Hull	
50	PGZ00163	Lithium Battery	
51	PGZ00139	Remote Controler	
54	PGZ00140	Right Cover Board Assembly	
56	#N/A	Engine Front Board	
57	#N/A	Engine Rear Board Body	
61	#N/A	Damping Pad	
62	#N/A	Framework Board	
64	#N/A	Damping Pad	
65	#N/A	Box Base	
66	#N/A	Shroud Cover	
68	#N/A	Connetion Plate	
69	#N/A	Wheel Shaft Assembly	

BASEFRAME

Position	Part Number	Description	Note
70	PGZ00045	Wheel	
72	#N/A	Adjustable Handle	
74	#N/A	Base	
75	#N/A	Service Window	
77	PGZ00126	Breaker	
78	PGZ00141	Socket	
79	#N/A	Earth Wire	
80	#N/A	Charger Port	
81	PGZ00142	Socket	
82	PGZ00128	Socket	
83	#N/A	Anode Terminal	
84	#N/A	Cathode Terminal	
85	PGZ00124	Stop Switch	
86	#N/A	Operation Indicator	
87	PGZ00131	Push-Button Start	
88	PGZ00143	Digital Meter	
89	PGZ00124	Stop Switch	
90	#N/A	Operation Indicator	
91	PGZ00127	Breaker	
92	PGZ00144	Socket	

ENGINE & ENGINE'S OPTIONS



ENGINE & ENGINE’S OPTIONS

Position	Part Number	Description	Note
2	#N/A	Dipstick	
3	#N/A	Valve Cover	
4	#N/A	O-Ring, Dipstick	
6	#N/A	Valve Cover	
7	#N/A	Gasket, Valve Cover	
8	#N/A	Inner Cover, Valve Cover	
10	#N/A	Gasket, Valve Cover	
11	#N/A	Push Rod	
13	#N/A	Rocker Arm Assembly	
14	#N/A	Rocker Arm Coreshaft	
15	#N/A	Valve Spring	
16	#N/A	Valve Adjust Cap, Exhaust	
17	#N/A	Valve Spring Seat	
18	#N/A	Valve Locker	
19	#N/A	Intake Valve Seal	
20	#N/A	Intake Vavle	
21	#N/A	Exhaust Valve	
23	PGZ00145	Cylinder Head	
24	PGZ00059	Spark Plug	
25	PGZ00146	Gasket, Carburetor Insulator	
26	#N/A	Insulator	
27	PGZ00147	Gasket, Carburetor	
28	#N/A	Stud, M6×95	
29	PGZ00148	Carburetor	
30	PGZ00149	Stepping Motor	

ENGINE & ENGINE’S OPTIONS

Position	Part Number	Description	Note
31	PGZ00150	Stepping Motor	
33	PGZ00151	Stepping Motor Cover	
34	PGZ00117	Gasket, Carburettor	
35	#N/A	Gasket, Air Filter	
37	#N/A	Breather Hose	
40	#N/A	Clamp, Fuel Hose	
41	PGZ00152	Air Filter Assembly	
43	#N/A	Gasket, Cylinder Head	
45	#N/A	Tappet	
46	#N/A	Piston Ring Set	
47	#N/A	Piston	
48	#N/A	Circlip	
49	#N/A	Piston Pin	
50	#N/A	Connecting Rod Assembly	
51	#N/A	Shroud	
53	#N/A	Crankcase	
58	PGZ00153	Spark Arrester	
59	PGZ00154	Muffler	
60	#N/A	Gasket, Muffler	
61	#N/A	Bush	
63	#N/A	Shroud	
64	#N/A	Crankcase Cover	
65	#N/A	Gasket, Crankcase	
67	#N/A	Bearing, TM6206E-P53	
68	#N/A	Crankshaft	

ENGINE & ENGINE’S OPTIONS

Position	Part Number	Description	Note
69	#N/A	Woodruff Key	
71	#N/A	Camshaft	
74	PGZ00155	Oil Sensor	
75	PGZ00156	Ignition Coil	
76	#N/A	Cathode Wire	
77	PGZ00157	Electric Starter	
80	#N/A	Oil Drain Pipe	
81	#N/A	Trigger Support	
83	#N/A	Trigger	
85	#N/A	Oil Seal, φ30×φ46×8	
86	#N/A	Stator Assembly	
88	#N/A	Rotor Assembly	
89	PGZ00158	Cooling Fan	
90	#N/A	Starter Cup	
93	#N/A	Blower Housing	
96	#N/A	Stud, M6-8×130.5	
97	#N/A	Stud, M6-8×140	
98	PGZ00103	Recoil Starter	
99	#N/A	Blower Housing	
101	#N/A	Idle Spring	
102	#N/A	Blower Housing	
104	#N/A	Wire Jacket	
108	#N/A	Fuel Hose	
109	#N/A	Clip	

ENGINE & ENGINE'S OPTIONS

Position	Part Number	Description	Note
110	PGZ00159	Temperature Sensor	
112	#N/A	Choke Lever Rack	
113	#N/A	Damping Pad	
114	#N/A	Support Frame	
116	#N/A	Resonant Cavity	
117	#N/A	Intake Tube	

PRAMAC

SERVICE & PARTS